

MAINTENANCE

Clean this unit with a soft, dry cloth. Never use alcohol, paint thinner or benzene to clean this unit.

PRODUCT SERVICE

- 1) **Damage requiring service:** The unit should be serviced by qualified service personnel if:
 - (a) The DC power supply cord or AC adaptor has been damaged;
 - (b) Objects or liquids have gotten into the unit;
 - (c) The unit has been exposed to rain;
 - (d) The unit does not operate normally or exhibits a marked change in performance;
 - (e) The unit has been dropped or the cabinet damaged.
- 2) **Servicing Personnel:** Do not attempt to service the unit beyond that described in these operating instructions. Refer all other servicing to authorized servicing personnel.
- 3) **Replacement parts:** When parts need replacing ensure the servicer uses parts specified by the manufacturer or parts that have the same characteristics as the original parts. Unauthorized substitutes may result in fire, electric shock, or other hazards.
- 4) **Safety check:** After repairs or service, ask the servicer to perform safety checks to confirm that the unit is in proper working condition.

WARRANTY

If your product does not work properly because of a defect in materials or workmanship, our Company (referred to as "the warrantor") will, for the length of the period indicated as below, **(Parts(2)Year, Labor(90) Days)** which starts with the date of original purchase ("Limited Warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor. During the "Labor" Limited Warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. You must mail-in your product during the warranty period. This Limited Warranty is extended only to the original purchaser and only covers product purchased as new. A purchase receipt or other proof of original purchase date is required for Limited Warranty service.


MAIL-IN SERVICE

When shipping the unit carefully pack and send it prepaid, adequately insured and preferably in the original carton. Include a letter detailing the complaint and provide a day time phone and/or email address where you can be reached.

SDI to HDMI Converter, With 1xlooping SDI output

Model: 125-0492

Operating Instructions



Dear Customer

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

FEATURES

- Convert SD/HD/3G-SDI to HDMI
- Distribute 1 SD/HD/3G-SDI to 1 HDMI plus 1 looping SDI output simultaneously
- Support SDI input resolutions:
1080p (50/60/59.94/30/29.97/24/23.98Hz)
1080i (60/59.94Hz), 720p (60/59.94/50Hz), 576i (50Hz), 480i (60/59.94Hz)
- Work with 125-0492 to cascade many layers
- Support transmission distance up to 100m over RG59 cable
- With mounting ears

NOTICE

Our company reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

TABLE OF CONTENTS

- Specifications
- Package Contents
- Panel Descriptions
- Connecting and Operating
- Maintenance
- Product service
- Warranty

SPECIFICATIONS


Operating Temperature	-5 to +35°C(+23 to +95°F)
Operating Humidity	5 to 90%RH (No Condensation)
Resolutions Formats	1080p@23.98/24/25/29.97/30/50/59.94/60HZ; 1080i@50/59.94/60HZ; 720P@50/59.94/60HZ; 576i @50HZ; 480i@59.94/60HZ
SDI Standard	3G-SDI/HD-SDI/SDI
Input	1x SDI(BNC)
Output	1x SDI(BNC) , 1x HDMI (Standard Type A connect
Output Impedance	75ohms
Power consumption	2.5watts(Maximum)
Dimension (LxWxH)	95x95x29mm
Net Weight	245g

Note: Specifications are subject to change without notice. Mass and dimensions are approximate.

PACKING CONTENTS

- 1) Main Unit. SDI-HDMI converter
- 2) DC5V 1A Power Supply.
- 3) Operating Instructions

PANEL DESCRIPTIONS



- 1) Indicator of HDMI Output
- 2) Indicator of power Input
- 3) SDI input port
- 4) SDI output port
- 5) HDMI output port
- 6) Power input

Connecting and Operating

1. Ensure the Converter is disconnected from power.
 2. Connect source to the SDI input and sink to HDMI output and SDI output.
 3. Connect 5VDC power to the converter.
- Attention: Insert/Extract cable gently

Typical Application

